

DELTA-50

Desktop PA with Bluetooth®

Item ref: 178.808UK

User Manual



Version 1.



Caution: Please read this manual carefully before operating
Damage caused by misuse is not covered by the warranty

Introduction

Thank you for choosing the DELTA-50 desktop PA unit. Please read this manual prior to use to gain the best from your product and to avoid damage through misuse.

This versatile portable PA unit is packed with features in a compact, manageable enclosure and is suitable for a wide array of applications ranging from public address for presentations to outdoor karaoke.

- Internal 12V rechargeable battery
- 2 x VHF handheld microphones included
- 2 wired microphone inputs (6.3mm jack)
- Master 2 band EQ and Echo effect for microphones
- Internal USB/SD/FM media player with Bluetooth
- Wireless remote control for media player
- Carry handle & Shoulder strap

Package Contents

Please check the contents to ensure that the product has been received in good condition.

- DELTA-50 desktop PA unit
- 2 x VHF handheld microphone transmitters
- IR Remote control for media player
- Shoulder strap
- Power adaptor
- User manual

If you find any accessory is missing or the product has arrived with any problems, please contact your retailer at once.

This product contains no user-serviceable parts so make no attempt to try to fix or modify this item yourself as this will invalidate the warranty. We recommend you keep the original package and proof of purchase for any possible replacement or returned demand.

Warning

To prevent the risk of fire or electric shock, do not expose this appliance to rain or moisture. To prevent electric shock do not remove the cover. No user serviceable parts inside. Refer servicing to qualified service personnel.

Safety

Prior to connecting mains, ensure that the supply voltage is correct and the mains lead is in good condition. Avoid ingress of water or particles into the enclosure.

If the VHF microphones are to be unused for a long period of time, remove the battery and store for later use.



Placement

Keep the unit out of direct sunlight and away from heat sources.
Place the unit in an upright position during use and storage.
Keep the unit away from moisture or dusty environments.

Cleaning

Use a soft cloth with a neutral detergent to clean the cabinet, panel and controls.
To avoid damage, do not use solvents to clean this equipment.

Controls



- 1 SD card slot
- 2 USB input
- 3 Media player LCD display
- 4 IR remote receiver
- 5 Wired microphones volume
- 6 Microphone Echo level control
- 7 Treble EQ control
- 8 Bass EQ control
- 9 Music volume control
- 10 Media player mode control
- 11 Media player transport/record controls
- 12 VHF antenna
- 13 VHF Mic A volume control
- 14 Radio Frequency indicator (channel A)
- 15 VHF Mic B volume control
- 16 Radio Frequency indicator (channel B)
- 17 Power on indicator
- 18 VHF power on/off switch
- 19 VCV activation switch
- 20 Power and battery charge indicators
- 21 Power switch
- 22 12-15Vdc power input
- 23 Mix line output (RCA)
- 24 Auxiliary line input (RCA)
- 25 3.5mm auxiliary input
- 26 MIC 2 input (6.3mm jack)
- 27 MIC 1 input (6.3mm jack)

Operation

Connection

Your new DELTA-50 desktop PA unit may arrive with you with the internal battery charged. Before connecting the 12Vdc adaptor to the mains, switch the unit on and see if the power LED lights. If not, you will need to charge the battery before using away from a mains supply (see **"Charging the battery"** below)

Connect the DELTA-50 to the mains supply by connecting the power adaptor provided to the 12-15Vdc power input (22). Observe the LEDs (20) adjacent to the DC power input. The lower LED is orange for charging and green when charged. The upper LED is green when powered on and red if the battery is low.

Power Up

Turn VOLUME, ECHO, MIC VOLUME and VHF MIC controls down (anti-clockwise) and turn the POWER switch on (the power LED should light). BASS and TREBLE controls should remain pointing vertically (12-o'clock position) – these can be altered later to give the overall appropriate tone shape. Your DELTA-50 desktop PA unit should now be ready to operate.

VHF Handheld Microphones

Insert the supplied AA batteries into the handheld microphones by carefully unscrewing the base of each and aligning the "+" and "-" ends of each cell as imprinted in the battery compartment. Take care to observe the correct polarity.

Press the VHF ON/OFF button on the DELTA-50 so that the VHF POWER LED lights.

Switch on each wireless mic by sliding up the switch fully – the RF LEDs on the DELTA-50 unit should light as a result. If the LED on the handset does not light or stays on dimly lit, change the battery and try again.

Gradually increase VHF VOL control, testing each microphone in turn for output through the DELTA-50 speaker. Take care not to incur "feedback" (howling or screeching sound through the speaker) by keeping the microphone a sensible distance from the speaker and pointing away from the speaker so that it doesn't "hear" the speaker output.

Turning the ECHO control clockwise introduces the echo effect for singing and special effects.

When not in use, switch the wireless microphones off. Remove batteries if not being used for long periods of time.

External Inputs

In addition to the unit's own VHF microphones, 6.3mm jack inputs are provided to connect external microphones, which are both governed by the MIC VOLUME control.

A VCV switch activates the Voice Controlled Volume feature.

This function gives priority to microphones over playback, so that announcements are more easily heard.

When the VCV is on, any sound through the microphones will cause the music playback to "duck" (drop in volume).

The music volume is restored after there is no sound through the microphone (after a short, preset period of time).

Also, an RCA LINE IN input is provided for line input sources such as CD player or personal audio player.

To use this input, select the AUX input mode using the media player MODE button.

The LINE IN is governed by the VOLUME control at the top of the panel and volume settings in the media player.

Below the RCA connectors is a 3.5mm jack input which operates in a similar way for a smart phone or mp3 player.

Above the LINE IN input is a pair of RCA connectors for MIX OUT, carrying the overall main mix to connected equipment.

Internal USB/SD player & Bluetooth receiver

The DELTA-50 onboard media player can play back files from USB/SD/FM media or a paired Bluetooth device.





Insert a USB memory stick or an SD card with compressed digital audio files stored on it into the relevant slot on the top panel. Playback will normally start automatically from the last media inserted (USB or SD).

If the LCD display shows a jack plug, press the USB/SD button and check that the LCD display shows that media is being read from the USB or SD device. If not, press the ►|| button or try removing and re-inserting the memory device.

Increasing the Master Volume control (21) should result in the audio being played through the speakers.

Panel controls are detailed below...



MODE	switches input between USB/SD/FM media or Bluetooth
	press for previous track
	press for next track
	Repeat mode
	Play/Pause playback

To connect a smart phone or other Bluetooth device to the DELTA-50 media player, open the Bluetooth menu on your device and search for "PA SYSTEM". Pair with this ID and connect (re-name if desired) in order to be able to play audio from the Bluetooth device to the DELTA-50.


Pressing the MODE button will select between Bluetooth and USB/SD playback sources.
 (Note: there is also an AUX setting which is not used, since the mixer section has separate line inputs)

Mute, volume and track navigation can be achieved via the media player control panel. Bluetooth pairing is always available for a single device so long as the device is within reception range. It may be necessary to re-connect if the device has moved out of range and disconnected.

Remote Control

In addition to the panel controls, an infra-red remote control is provided for the USB/SD player which adds some further functions to allow greater control over the media player.

To operate, remove the clear plastic tab from the remote to activate the battery.



Charging the internal battery

When not in use but connected via the 12Vdc adapter to the mains, if the POWER switch is in the *off* position, the internal battery will be re-charged from the mains supply. This can be observed by the CHARGE LED which lights when charging.

Specifications

Power supply	12-15Vdc (adaptor supplied) or internal battery
Battery life	Up to 8 hours
HF driver	2 x 25mmØ balanced dome
LF Driver	200mm (8") reinforced paper cone
Bluetooth version	2.1
Output power	50Wrms
SNR	85dB
Construction	Injection-moulded polypropylene
Power supply : Handheld transmitters	2 x AA batteries each microphone
Wireless microphone frequencies	174.1MHz + 175.0MHz
Dimensions	380 x 295 x 220mm
Weight	7.2kg

Troubleshooting

No output and no LEDs lit	Check POWER switch is on
	Check battery is not drained fully
	Check mains lead is connected if not on battery power
Power LED lit but no VHF output	Check AA batteries in handheld transmitters
	Check VHF POWER is switched on
	Check VOL controls are not turned down on top panel
Bluetooth not connecting	Check RF LED is lit for each channel (check transmitter frequency)
	Ensure that the smart phone or tablet is paired to "PA System"
Power LED lit but no media player output	Check that the sending device is within range – usually 5 to 8m
	Check USB or SD has mp3 audio files stored
	Check USB or SD is connected properly
	Ensure media is formatted to the FAT32 file system
	Press MODE button and try Play/Pause button
	In FM tuner mode, ensure that a station is tuned in
	Check VOLUME is not turned down
	Press and hold "VOL +" button to ensure media player volume is up
Check LCD display to see moving numbers	
Power LED lit but no sound from external inputs	Check leads are in good condition and connected properly
	Check volume and on/off switch on external mic or line source
	Check VOLUME or MIC VOLUME control is not fully down
	In AUX mode, press Play/Pause to ensure input is not muted



Disposal: The "Crossed Wheelie Bin" symbol on the product means that the product is classed as Electrical or Electronic equipment and should not be disposed with other household or commercial waste at the end of its useful life. The goods must be disposed of according to your local council guidelines.

*Errors and omissions excepted.
Copyright© 2018. AVSL Group Ltd.*